



Cletop -S Series



Cletop Series

NOYES® Cletop Cassette Cleaner Series

The Cletop connector cleaner is a rugged palm-sized cleaner that offers exceptional performance with a proven track record. The choice of many leading manufacturers and telecom carriers worldwide for nearly 20 years – Cletop is a name you can rely on.

Why Clean Fiber Connectors?

- Pits and scratches are often caused by dirt
- Dust, dirt, oils, etc. are everywhere and will migrate to exposed connector end-faces
- Dirty connectors attenuate signal levels and can increase digital bit error rates
- Always clean both connectors when mating / unmating to avoid contamination transfer

Cletop Cassette Cleaner Options

- Cletop Series - Original version (proven reliability)
- Cletop –S Series - Second generation cleaner offering the same Cletop cleaning performance with “Drop-in” replacement tape cartridge and ergonomic design that works equally well for left or right handed operators
- Type A and -SA - Designed for single 2.5mm ferrules (SC, FC, ST, & D4)
- Type B and -SB - Cleans SC, SC2, FC, ST®, DIN, D4, MU, LC, MT, MPO/MTP® without pins, MT-RJ without pins
- Type MPO - Accepts MPO/MTP connectors with pins
- Type MT-RJ - Accepts MT-RJ connectors with pins

Features

- Compact and lightweight design is ideal for use in laboratories, assembly lines, or in the field
- Consistent cleaning results without IPA alcohol, which is toxic, flammable, and leaves a residue on fiber ends (white haze)
- Excellent anti-static properties for static sensitive applications and to minimize reattachment of dust to ferrule after cleaning
- Simple push button shutter operation exposes cleaning tape only when in use – minimizing unwanted dust
- Replaceable and cost effective cleaning tape
- Over 400 wipes per tape

**NOYES®
Cletop Cassette Cleaner Series**

Specifications

Size	130 x 75 x 40 mm (5.1 x 3.0 x 1.6 in)
Weight	160 g/0.35 lb

Ordering Information

DESCRIPTION	AFL NO.
CLETOP – S SERIES	
Cletop -SA with Blue Tape	8500-10-0020MZ
Cletop -SB with Blue Tape	8500-10-0029MZ
Cletop -SB with White Tape	8500-10-0016MZ
Replacement Tape Type S - Blue	8500-10-0021MZ
Replacement Tape Type S - White	8500-10-0017MZ
CLETOP ORIGINAL SERIES	
Cletop Type A with Blue Tape	8500-10-0027MZ
Cletop Type A with White Tape	8500-10-0011MZ
Cletop Type B with Blue Tape	8500-10-0028MZ
Cletop Type B with White tape	8500-10-0014MZ
Cletop for MT-RJ with pins (White Tape)	8500-10-0032MZ
Cletop for MPO/MTP with pins (White Tape)	8500-10-0033MZ
Replacement Tape Blue	8500-10-0012MZ
Replacement Tape White	8500-10-0015MZ

Authorized Channel Partner



United States
Customer Service
1.800.321.5298
1.603.528.7780
www.AFLglobal.com

Europe, Middle East, Africa
Max Penfold
Max.Penfold@AFLglobal.com
+44 1799 542 840
+44 7802 839 160

Middle East
Ahmed El Sakaty
Ahmed.ElSakaty@AFLglobal.com
+20 106 451 523

Africa (Sub Sahara)
Nicholas Cole
Nicholas.Cole@AFLglobal.com
+44 7702 005 590

Greater China
Dai Liu
Dai.Liu@AFLglobal.com
+86 133 1101 4533

Asia-Pacific (non-China)
Saw Biing Huei
Biing.Saw@AFLglobal.com
+65 9791 3398